

6.Installing the Wire Covers



Install the wire covers to secure cables into place.

7. Adjustment



Adjust to desired angle.

Maintenance
- Check that the bracket is secure and safe to use at regular intervals(at least every three months).
- Please contact your distributor if you have any questions.

INSTALLATION MANUAL

Short Throw Projector Wall Mount



PRB-14
PRB-14M
PRB-14S

CAUTION: DO NOT EXCEED RATED LISTED WEIGHT. SERIOUS INJURY OR PROPERTY DAMAGE MAY OCCUR!

ISSUED: NOV. 2013

NOTE: Read the entire instruction manual before you start installation and assembly.

⚠ WARNING

- Do not begin the installation until you have read and understood all the instructions and warnings contained in this installation sheet. If you have any questions regarding any of the instructions or warnings, please contact your local distributor.
- This mounting bracket was designed to be installed and utilised ONLY as specified in this manual. Improper installation of this product may cause damage or serious injury.
- This product should only be installed by someone with good mechanical ability who has basic building experience and fully understands this manual.
- Make sure that the supporting surface will safely support the combined weight of the equipment and all attached hardware and components.
- Always use an assistant or mechanical lifting equipment to safely lift and position the equipment.
- Tighten screws firmly, but do not over tighten. Over tightening can cause damage to the items, This greatly reduces their holding power.
- This product is intended for indoor use only. Using this product outdoors could lead to product failure and personal injury.

Component Checklist

IMPORTANT: Ensure that you have received all parts according to the component checklist prior to installation. If any parts are missing or faulty, telephone your local distributor for a replacement.



Package M



Package W



1. For Solid Brick and Concrete Mounting







Mark the exact location of mounting holes

Drill pilot holes







Screw the projector arm A onto the wall.

⚠ WARNING

Installers must verify that the supporting surface will safely support the combined weight of the equipment and all attached hardware and components.

2. Installing the Wall Plate Cover and Cable Management



Run the cable through the projector arm A.
Then slide the wall plate cover along the arm A until it snap shut onto the wall plate.



Run the cable through the projector arm B.
Then insert the projector arm B into the projector arm A at the desired position, and slide the blanking cover along arm B until it snap shut onto the end of arm A. Use screws to fix the blanking cover and tighten all screws with a M4 anti-theft tool.



3. Installing the Arms



Note: If there are only three mounting holes using three arms.

Important: If the projector has less than three mounting holes, do not use this projector bracket.



Position the holes of arms over mounting holes.

Screw the arms onto the projector.

⚠ **TIGHTEN ALL SCREWS BUT DO NOT OVER TIGHTEN!**



Install decorative covers onto the arms.



4.Installing the Projector Plate



Fasten the projector plate with a 6mm Allen key.

It is necessary to loosen or tighten the adjustment screws with a 4mm Allen key according to the weight of the projector.





Attach the projector plate to the arms(with attached projector) using appropriate screws and washers.

Insert projector plate cover onto the projector plate.

5. Attach the Projector to Projector Arm





Attach the projector plate (with attached projector) to projector arm using appropriate screws,and tighten screws to secure with a M4 anti-theft tool.

Install the end cap onto the projector plate assembly.